

# SIEMENS



## Semi-flush mount room thermostats with KNX communications **RDU341**

### Basic Documentation

Edition: 1.0

CE1P3172en  
20 Jul 2010

**Building Technologies**

# Contents

---

<b>1.</b>	<b>About this document .....</b>	<b>4</b>
1.1	Revision history.....	4
1.2	Reference documents .....	4
1.3	Before you start.....	5
1.3.1	Copyright.....	5
1.3.2	Quality assurance .....	5
1.3.3	Document use / request to the reader .....	5
1.4	Target audience, prerequisites .....	6
1.5	Glossary .....	6
<b>2.</b>	<b>Summary .....</b>	<b>7</b>
2.1	Types.....	7
2.2	Ordering .....	7
2.3	Functions.....	7
2.4	Integration via KNX bus .....	8
2.5	Equipment combinations.....	10
2.6	Accessories .....	11
<b>3.</b>	<b>Functions .....</b>	<b>12</b>
3.1	Temperature control .....	12
3.2	Operating modes.....	13
3.2.1	Different ways to influence the operating mode .....	14
3.2.2	Communication examples.....	17
3.3	Room temperature setpoints.....	19
3.3.1	Description .....	19
3.3.2	Setting and adjusting setpoints .....	20
3.4	Applications overview.....	22
3.5	Additional functions .....	23
3.6	Control sequences .....	25
3.6.1	Sequences overview (setting via parameter P01) .....	25
3.6.2	Application mode.....	26
3.6.3	Minimum and maximum air volume .....	28
3.6.4	Single-duct .....	29
3.6.5	Single-duct with electric heater .....	30
3.6.6	Setpoints and sequences .....	32
3.7	Control outputs .....	33
3.7.1	Overview .....	33
3.7.2	Control outputs configuration (setting via DIP switches or tool) .....	33
3.8	Multifunctional input, digital input .....	34
3.9	Handling faults.....	36
3.10	KNX communications .....	36
3.10.1	S-mode.....	36
3.10.2	LTE mode .....	36
3.10.3	Zone addressing in LTE mode (in conjunction with Synco) .....	37
3.10.4	Example of heating and cooling demand zone .....	39
3.10.5	Send heartbeat and receive timeout .....	40
3.10.6	Startup .....	40
3.10.7	Heating demand .....	40

3.10.8	Air demand.....	40
3.10.9	Electric heater interlock by supply air controller (LTE mode only).....	41
3.10.10	Primary fan overrun after switching off the electric heater.....	41
3.10.11	Fault function on KNX .....	42
3.10.12	Emergency control (LTE Mode only).....	43
3.11	Communication objects (S-mode).....	44
3.11.1	Overview .....	44
3.11.2	Description of communication objects .....	45
3.12	Control parameters .....	47
3.12.1	Parameter setting via local HMI .....	47
3.12.2	Parameter setting / download via tool.....	48
3.12.3	Parameters of the "Service level" .....	49
3.12.4	Parameters of the "Expert level with diagnostics and test".....	50
<b>4.</b>	<b>Handling.....</b>	<b>52</b>
4.1	Mounting and installation .....	52
4.2	Commissioning.....	52
4.3	Operation .....	54
4.4	Remote operation.....	56
4.5	Disposal .....	56
<b>5.</b>	<b>Supported KNX tools.....</b>	<b>57</b>
5.1	ETS3 Professional .....	57
5.1.1	Parameter settings in ETS Professional .....	57
5.2	ACS700 Service and Operating tool.....	57
5.2.1	Parameter settings in ACS.....	58
5.2.2	Operation and monitoring with ACS.....	59
5.2.3	Operation and monitoring with OZW772 .....	61
5.2.4	Operation and monitoring with RMZ972 .....	61
<b>6.</b>	<b>Connection .....</b>	<b>62</b>
6.1	Connection terminals .....	62
6.2	Connection diagrams .....	62
<b>7.</b>	<b>Mechanical design .....</b>	<b>63</b>
7.1	General .....	63
7.2	Dimensions .....	64
<b>8.</b>	<b>Technical data .....</b>	<b>65</b>
<b>Index</b>	.....	<b>67</b>

# 1. About this document

## 1.1 Revision history

Edition	Date	Changes	Section	Pages
1.0	16 Jul 2010	First edition	all	

## 1.2 Reference documents

Subject	Ref	Doc No.	Description
Semi-flush mount room thermostats with KNX communications, RDU341	[1]	CE1N3172	Data Sheet
	[2]	CE1B3172	Operating Instructions
	[3]	CE1M3172	Mounting Instructions
KNX Manual	[4]		Handbook for Home and Building Control – Basic Principles ( <a href="http://www.knx.org/uk/news-press/publications/publications/">www.knx.org/uk/news-press/publications/publications/</a> )
Synco and KNX (see <a href="http://www.siemens.com/synco">www.siemens.com/synco</a> )	[5]	CE1N3127	KNX bus, Data Sheet
	[6]	CE1P3127	Communication via the KNX bus for Synco 700, 900 and RXB/RXL, Basic Documentation
	[7]	XLS template in HIT	Planning and commissioning protocol, communication Synco 700
	[8]	CE1N3121	RMB395 central control unit, Data Sheet
	[9]	CE1Y3110	KNX S-mode data points
	[10]	--	Product data for ETS3
	[11]	CE1J3110	ETS product data compatibility list
	[12]	0-92168en	Synco Application Manual
DESIGO engineering documents	[13]	CM1Y9775	DESIGO RXB integration – S-mode
	[14]	CM1Y9776	DESIGO RXB / RXL integration – Individual Addressing
	[15]	CM1Y9777	Third-party integration
	[16]	CM1Y9778	Synco integration
	[17]	CM1Y9779	Working with ETS
Apogee engineering documents (RDU341... only)	[18]	565-132	Installation Instructions: KNX driver for PXC Modular
	[19]	127-1676	Technical Spec Sheet: KNX driver for PXC Modular
	[20]	140-0804	Technical reference for KNX driver
	[21]	TBD	Application 6205 point map for RDU

## **1.3 Before you start**

### **1.3.1 Copyright**

---

This document may be duplicated and distributed only with the express permission of Siemens, and may be passed only to authorized persons or companies with the required technical knowledge.

### **1.3.2 Quality assurance**

---

This document was prepared with great care.

- The contents of this document is checked at regular intervals
- Any corrections necessary are included in subsequent versions
- Documents are automatically amended as a consequence of modifications and corrections to the products described

Please make sure that you are aware of the latest document revision date.

If you find lack of clarity while using this document, or if you have any criticisms or suggestions, please contact the Product Manager in your nearest branch office.

The addresses of the Siemens Regional Companies are available at

[www.buildingtechnologies.siemens.com](http://www.buildingtechnologies.siemens.com).

### **1.3.3 Document use / request to the reader**

---

Before using our products, it is important that you read the documents supplied with or ordered at the same time as the products (equipment, applications, tools, etc.) carefully and in full.

We assume that persons using our products and documents are authorized and trained appropriately and have the technical knowledge required to use our products as intended.

More information on the products and applications is available:

- On the intranet (Siemens employees only) at  
<https://workspace.sbt.siemens.com/content/00001123/default.aspx>
- From the Siemens branch office near you  
[www.buildingtechnologies.siemens.com](http://www.buildingtechnologies.siemens.com) or from your system supplier
- From the support team at headquarters [fieldsupport-zug.ch.sbt@siemens.com](mailto:fieldsupport-zug.ch.sbt@siemens.com) if there is no local point of contact

Siemens assumes no liability to the extent allowed under the law for any losses resulting from a failure to comply with the aforementioned points or for the improper compliance of the same.

## 1.4 Target audience, prerequisites

---

This document assumes that users of the RDU KNX thermostats are familiar with the ETS3 Professional and/or Synco ACS700 tools and able to use them.

It also presupposes that these users are aware of the specific conditions associated with KNX.

In most countries, specific KNX know-how is conveyed through training centers certified by the KNX Association (see [www.konnex.org/](http://www.konnex.org/)).

For reference documentation, see section 1.2.

## 1.5 Glossary

---

The inputs, outputs and parameters of an application can be influenced in various ways. These are identified by the following symbols in this document:



### ETS3 Professional

Parameters identified by this symbol are set using ETS3 Professional.



### ACS Service

Parameters identified by this symbol are set using the ACS Service tool.



### ACS Operating

Parameters identified by this symbol can be monitored using the ACS Operating tool.



### Note!

**Setting RDU KNX parameters is only supported by the following tool versions:**

- ETS3f or higher
- ACS700 version 5.11 or higher



Inputs and outputs identified by this symbol communicate with other KNX devices. They are called communication objects (CO).

The communication objects of the RDU KNX thermostats work partly in S-mode, partly in LTE mode, and partly in both. These objects are described accordingly.

A list of the parameters is shown in section 3.12.

## 2. Summary

### 2.1 Types

Product number	Stock number	Operating voltage	Control outputs			Housing color
			3 pos	ON/OFF	DC 0..10 V	
RDU341	S55770-T106	AC 24 V	--	✓	✓	white

### 2.2 Ordering

- When ordering, please indicate both product no. / stock no. and name:  
E.g. **RDU341 / S55770-T106 room thermostat**
- Order valve actuators separately

### 2.3 Functions

#### Use

**VAV systems** via ON/OFF or modulating control outputs:

- Single-duct system
- Single-duct system with electric heater

The room thermostats are delivered with a fixed set of applications.

The relevant application is selected and activated during commissioning using one of the following tools:

- Syncro ACS
- ETS3 Professional  
*Parameter and application download with ETS3 will be implemented later*
- Local DIP switch and HMI

#### Features

- Operating modes: Comfort, Economy (Energy Saving) and Protection
- Outputs for DC 0...10 V actuator and AC 230V electrical heater (ON-OFF)
- Automatic or manual heating / cooling changeover
- Backlit display
- AC 24 V operating voltage

#### Functions

- Room temperature control via built-in temperature sensor or external room temperature / return air temperature sensor
- Changeover between heating and cooling mode (automatic via local sensor or bus, or manually)
- Selection of applications via DIP switches or commissioning tool (ACS700).  
*Parameter and application download with ETS3 will be implemented later*
- Select operating mode via operating mode button on the thermostat
- Temporary Comfort mode extension
- Display of current room temperature or setpoint in °C and/or °F
- Display of outdoor temperature or time of day via KNX bus
- Minimum and maximum limitation of room temperature setpoint
- Minimum and maximum limitation of air flow signal DC 0...10 V
- Button lock (automatically or manually)

- 2 multifunctional inputs, freely selectable for:
  - Operating mode switchover contact (keycard, window contact, etc.)
  - Sensor for automatic heating / cooling changeover
  - External room temperature or return air temperature sensor
  - Dew point sensor
  - Electric heater enable
  - Fault input
  - Monitor input for temperature sensor or switch state
- Reload factory settings for commissioning and control parameters

## 2.4 Integration via KNX bus

---

The RDU room thermostats can be integrated as follows:

- Integration into Synco 700 system via LTE mode (easy engineering)
- Integration into Synco living via group addressing (ETS3)
- Integration into DESIGO and Apogee via group addressing (ETS3) or individual addressing
- Integration into third-party systems via group addressing (ETS3)

The following KNX functions are available:

- Central time program and setpoints, e.g. when using the RMB795 central control unit
- Outside temperature or time of day via bus displayed on thermostat
- Remote operation and monitoring, e.g. using the RMZ792 bus operator unit
- Remote operation and monitoring with web browser using the OZW772 or OZW775 web server
- Maximum energy efficiency due to exchange of relevant energy information, e.g. with Synco 700 controllers (e.g. heating demand, cooling demand)
- Alarming, e.g. external fault contact, condensation, etc.
- Monitoring input for temperature sensor or switch

Engineering and commissioning can be done using...

- local DIP switches / HMI
- Synco ACS700 service tool
- ETS3 Professional

*Parameter and application download with ETS3 will be implemented later*


### Synco 700

The RDU room thermostats are especially tailored for integration into the Synco 700 system and operate together in LTE mode. This extends the field of use of Synco for individual room control in conjunction with VAV.

### Synco living

Thanks to S-mode extension to the QAX910 central apartment unit, communicating room thermostats can be easily integrated into Synco living systems. Using the S-mode data points of the central apartment unit, additional room information can be exchanged with the room thermostat via KNX TP1 (RF function is not available on the room thermostats). To make the integration, the ETS3 engineering tool is required.

## Synco topology



### Legend:

Synco 700	Building automation and control system (BACS)
Synco living	Room automation and control system
RDG..., RDF..., RDU...	Room thermostats
OZW772 (or OZW775)	Web server
RMZ792	Bus operator unit
QAW...	Room unit
ACS700	Service tool using OCI700.1 (OCI700.1 is delivered with a service cable which can be plugged into the service connector on a Synco controller)
RXB, RXL	Room controllers
QAX	Room unit for RXB / RXL room controllers

### DESIGO, Apogee and third-party systems

The RDU KNX devices can be integrated into the Siemens building automation and control systems (BACS) DESIGO / Apogee or into 3rd-party systems. For integration, either S-mode (group addressing) or individual addressing can be used. The workflow for integration into DESIGO / Apogee is the same as with standard KNX devices.

## 2.5 Equipment combinations

Type of unit	Product no.	Data sheet
Cable temperature sensor	QAH11.1	1840
Room temperature sensor	QAA32	1747
Condensation detector / Supply unit	QXA2000 / QXA2001 / AQX2000	1542
DC 0..10 V valve actuators		
Electrical actuator, DC 0..10 V (for radiator valve)	SSA61...	4893
Electrical actuator, DC 0..10 V (for 2 and 3 port valves / V...P45)	SSC61...	4895
Electrical actuator, DC 0..10 V (for small valve 2,5 mm)	SSP61...	4864
Electrical actuator, DC 0..10 V (for small valves 5,5 mm)	SSB61...	4891
Electrical actuator, DC 0..10 V (for Combi-valve VPI45)	SSD61...	4861
Electromotoric actuator, DC 0..10V (for valves 5,5 mm)	SQS65...	4573
Thermal actuator, DC 0..10 V (for small valves and radiator valves)	STS61	4880
DC 0..10 V damper actuators		
	GQD161...	4605
	GDB161...	4634
	GLB161...	
DC 0...10 V damper actuator		
	GMA161...	4614
	GEB161...	4621
	GCA161...	4613
	GBB161...	4626
	GIB161...	
VAV compact controller	GDB181.1E/3	3544
	GLB181.1E/3	

## 2.6 Accessories

Description	Product no / Stock no.	Data sheet
Changeover mounting kit (50 pcs / package)	<b>ARG86.3</b>	N3009
Plastic mounting bracket for RDU semi-flush-mount thermostats for increasing the headroom in the conduit box by 10 mm	<b>ARG70.3</b>	N3009
Conduit box for semi-flush mounted thermostat	<b>ARG71 / S55770-T137</b>	N3009
KNX power supply 160 mA (Siemens BT LV)	<b>5WG1 125-1AB01</b>	--
KNX power supply 320 mA (Siemens BT LV)	<b>5WG1 125-1AB11</b>	--
KNX power supply 640 mA (Siemens BT LV)	<b>5WG1 125-1AB21</b>	--

### 3. Functions

#### 3.1 Temperature control

**General note:**  
**Parameters**

Setting of the control parameters (P01, etc., mentioned throughout the document) is described in section 3.12.

**Temperature control**

The thermostat acquires the room temperature via built-in sensor, external room temperature sensor (QAA32), or external return air temperature sensor (QAH11.1), and maintains the setpoint by delivering actuator control commands to heating and/or cooling equipment. The following control outputs are available:

- VAV box / damper: Modulating PI/P control with DC 0...10 V
- El. heater: ON/OFF control (2-position)

The switching differential or proportional band is 2 K for heating mode and 1 K for cooling mode (adjustable via parameters P30 and P31).

The integral action time for modulating PI control is 5 minutes (adjustable via parameter P35).

**Display**

The display shows the acquired room temperature or the Comfort setpoint, selectable via parameter P06. The factory setting displays the current room temperature. Use parameter P04 to display the room temperature or setpoint in °F rather than °C as needed.



Room temperature



- With automatic changeover or continuous heating / cooling, symbols indicate that the system currently heats or cools (heating or cooling output is activated).
- With manual changeover (P01 = 2), symbols indicate that the system currently operates in heating or cooling mode. Thus, the symbols are displayed even when the thermostat operates in the neutral zone.

Concurrent display of °C and °F

Concurrent display of the current temperature or setpoint in °C and °F (parameter P07 = 1) is possible on the thermostats.



Outside temperature via bus

The outside temperature can be displayed on the room thermostat by setting parameter P07 = 2. This temperature value has only information character.

In LTE mode, the outside temperature can only be received on outside temperature zone 1.

In S-mode, the corresponding communication object needs to be bound with a KNX sensor device.



Time of day via bus

Time of day via bus can be displayed on the room thermostat by setting parameter P07 = 3 or 4. The display format is either in 12- or in 24-hour format.

The information can be received from a Synco controller with time master functionality or any other KNX device if the corresponding communication object is bound.

## 3.2 Operating modes

The thermostat's operating mode can be influenced in different ways (see below). Specific heating and cooling setpoints are assigned to each operating mode.



Room operating mode:  
State

The thermostat sends the effective room operating mode on the bus.

**Auto Timer** 

In Auto Timer mode the room operating mode is commanded via bus.  
Auto Timer is replaced by Comfort when no time schedule via bus is present

**Comfort** 

In Comfort mode, the thermostat maintains the Comfort setpoint. This setpoint can be defined via parameters P8, P9 and P10.  
It can be locally adjusted via the +/- buttons or via bus.  
In Comfort mode, the fan can be set to automatic or manual fan speed: Low, medium or high.

**Economy** 

The setpoints (less heating and cooling than in Comfort mode) can be defined via parameters P11 and P12.

The thermostat switches to Economy mode when...

- the operating mode button is pressed (only possible if parameter P02 is set to 2)
- Economy is sent via bus
- an operating mode switchover contact (e.g. keycard contact presence detector, window contact) is active.  
The contact can be connected to multifunctional input X1, X2.  
Set parameter P38 / P40 to 3 (P02 is irrelevant \*)
- "Window state" is sent via bus, e.g. from a KNX switch or a KNX presence detector (P02 is irrelevant \*)

Note: \*) Operating mode switchover: *Only one input source must be used, either local input X1/X2 or KNX bus.*

*User operations are ineffective and "OFF" is displayed if the operating mode switchover contact is active, or if "Window state" is sent via bus.*

**Protection** 

In Protection mode, the system is...

- protected against frost (factory setting 8 °C, can be disabled or changed via P65)
- protected against overheating (factory setting OFF, can be enabled or changed via P66)

No other operating mode can be selected locally if Protection mode is commanded via bus.  and  are displayed.

### 3.2.1 Different ways to influence the operating mode

Source for change of operating mode
 ACS Service
 ACS Operating

The operating mode can be influenced by different interventions. The source of the effective room operating mode state can be monitored using the "Cause" diagnostic data point in the ACS700 tool, operator unit RMZ792 or web server OZW772 / 775.

Source	Description	Value of DP "Cause"
Local operation via operating mode button	<ul style="list-style-type: none"> <li>Operating mode is not Auto Timer</li> <li>No time schedule via bus</li> <li>Temporary Comfort extension is active</li> <li>Operating mode switchover contact</li> </ul>	Room operating mode selector (preselection) "Timer" function Room operating mode contact
Bus command  	"Window state" sent via bus	Room operating mode contact
Room op. mode	<ul style="list-style-type: none"> <li>Time schedule available via bus → local operating mode is set to Auto Timer</li> <li>Time schedule sends Protection mode via bus → operating mode cannot be changed locally</li> </ul>	Time switch

#### Priority of operating mode interventions

The following table shows the priorities of different interventions. A lower number means a higher priority.

Priority	Description	Remark
①	Commissioning	In parameter setting mode (highest priority), you can always command an operating mode independent of all other settings or intervention via bus and local input.
②	Protection mode via bus from time schedule	Protection mode, sent by a time schedule, has priority 2. It cannot be overridden by the user nor by an operating mode switchover contact.
③	Operating mode switchover contact	If the contact is closed, the operating mode changes to Economy. This overrides the operating mode on the thermostat.
③	"Window state" via bus	"Window state" sent via bus has the same effect as the operating mode switchover contact. <i>Note: Only one input source must be used, either local input X1/X2 or KNX bus.</i>
④a	Operating mode button	The user can switch the operating mode using the operating mode button.
④b	Operating mode via bus	The operating mode can be changed via bus
④c	Temporary extended Comfort mode via operating mode button	The operating mode can be temporarily set from Economy to Comfort by pressing the operating mode button, if... <ul style="list-style-type: none"> <li>Economy was sent via bus</li> <li>extended Comfort period &gt;0 (parameter P68)</li> </ul> <i>The last intervention wins, either locally or via bus</i>
⑤	Time schedule via bus	The operating mode sent via bus can be overridden by all other interventions. <i>Exception: Protection mode has priority 2.</i>

**Auto Timer mode** 

**with time schedule via bus**

If a time schedule via bus is present, e.g. from central control unit, then the Auto Timer mode  is active. The thermostat automatically changes between Comfort and Economy according to the time schedule via bus.

The display shows the Auto Timer mode symbol  along with the symbol for the effective room operating mode (Comfort  or Economy ).

By pressing the operating mode button, you can change to another operating mode.

Automatic fan is the default fan speed in Auto Timer mode.

**Behavior when bus sends new operating mode**

Each time the time schedule sends a new operating mode (switching event), the operating mode of the thermostat is set back to Auto Timer mode. This is to assure that the room temperature is maintained according to the time schedule.

**Precomfort via bus**

If the time schedule sends Precomfort mode, then this mode will be transformed either into Economy (factory setting) or Comfort (selectable via parameter P88).

**Behavior when bus sends Protection**

No intervention is possible neither by the user nor by an operating mode switch-over contact, if Protection mode is set by the time schedule. OFF flashes on the display when the user presses a button.

**Availability of Economy mode**

The operating mode can be selected locally via the operating mode button. The behavior of the operating mode button (user profile) can be defined via parameter P02, factory setting is P02 = 1.

P02	Without time schedule	With time schedule via bus	Description
1	 → 	 → 	<ul style="list-style-type: none"> <li>Switching manually between <b>2</b> modes, Economy is not available (factory setting)</li> <li>Suited for hotel guest rooms or commercial buildings.</li> <li>If a time schedule via bus is available, then the Comfort mode can be temporarily extended (see below)</li> </ul>
2	 →  → 	 →  →  → 	<ul style="list-style-type: none"> <li>Switching manually between <b>3</b> modes</li> <li>Suited for homes and rooms where manual switching to Economy mode is desired</li> </ul>

**Operating mode switchover contact (window contact)**

The thermostat can be forced into Economy mode (e.g. when a window is opened, when a presence detector signals "no one present", when the keycard of a hotel room is withdrawn, etc). The contact can be connected to multifunctional input X1, X2. Set parameter P38, P40 to 3.

If the operating mode switchover contact is active, pressing the operating mode button will show "OFF" (blinking).



Room operating mode:  
Window state

The function is also available via the KNX signal "Window state", e.g. from a KNX switch or a KNX presence detector.

*Note: Only one input source must be used, either local input X1/X2 or KNX bus. User operations are ineffective and "OFF" is displayed if the operating mode switchover contact is active, or if "Window state" is sent via bus.*

## **Temporary timer to extend the Comfort mode**

Comfort mode can be temporarily extended (e.g. working after business hour or on weekends) when the thermostat is commanded to Economy mode.

The operating mode button switches the operating mode back to Comfort for the period preset in P68.

Press the operating mode button again to stop the timer.

The following conditions must be fulfilled:

- Mode selection via operating mode button is set to "Protection-Auto" (P02 = 1) and parameter P68 (extend Comfort period) is greater than 0
- The time schedule via bus is Economy or Operating mode switchover is active

During the temporary Comfort mode extension, symbol  appears.

If parameter P68 (extend Comfort period) = 0, extended Comfort cannot be activated; pressing the operating mode button will switch the thermostat to Protection.

### 3.2.2 Communication examples

The following examples show two typical applications of a central time schedule in conjunction with local control of the room operating mode.

The room operating mode in rooms 1...2 of a building is determined by the time schedule. Window contacts are fitted in all rooms.

The following conditions are specified:

The rooms are used and controlled by the time schedule as follows:

- Night setback from 17:00 to 08:00 (Economy)
- Protection from 20:00 to 06:00
- Lunch break from 12:00 to 13:00 (Precomfort)

The substitution (parameter P88) for Precomfort via bus is set on the thermostats as follows:


- Room 1: Comfort (1)
- Room 2: Economy (0)

#### Example 1

#### Operating mode switchover

In **room 1**, the window is opened briefly, once in the morning, once in late afternoon and once at night (1). Only the opening in the morning has a direct impact on the effective room operating mode.

During lunch break, the time schedule changes to Precomfort. The mode remains in Comfort as set by parameter “Transformation Precomfort” (P88 = 1).




## Example 2

### Interaction of user operation (operating mode button) and central time schedule

In room 2, the window is opened briefly, once in the morning and once at night (1). Only the opening in the morning has a direct impact on the effective room operating mode.

With the operating mode button, the operating mode can be changed between OFF and Auto or temporary Comfort extension respectively.

- During lunch break, the time schedule changes to Precomfort. The mode of the thermostat changes to Economy as set by parameter "Transformation Precomfort" (P88 = 0) (6)
- During lunch break, the user changes the operating mode to Comfort (temporary Comfort extension) by pressing the operating mode button (2). At 13:00, the timer is reset due to mode change of the central time schedule
- In the afternoon, the user switches the thermostat off by pressing the operating mode button (3). At 17:00 the user setting is reset to Economy by the time schedule
- At 19:30, the user again extends the Comfort mode (4). At 20:00, the timer is reset by the time schedule
- After 20:00, pressing the operating mode button has no effect, as the central time switch sets the thermostat to Protection (5)



### 3.3 Room temperature setpoints

#### 3.3.1 Description

**Comfort mode** ☀ The factory setting for the Comfort basic setpoint is **21 °C** and can be changed in the thermostat's EEPROM via parameter P08 or via bus with communication object "Comfort basic setpoint". The last intervention always wins.


The Comfort setpoint can be adjusted via +/- buttons, or via bus from a remote device like a touchpanel, operating unit, etc.  
The last intervention always wins.

**Temporary setpoint** If the "Temporary setpoint" function is enabled via parameter P69, the Comfort setpoint adjusted via the +/- buttons or via bus is set back to the Comfort basic setpoint stored in P08 when the operating mode changes.

**Setpoint limitation** For energy saving purposes, the setpoint setting range can be limited to minimum (P09) and maximum (P10).

**P09 < P10** • If the minimum limit **P09 is set lower** than the maximum limit P10, both heating and cooling are adjustable between these 2 limits

**P09 ≥ P10** • For heating **or** cooling applications (e.g. single duct):  
– The setting range in cooling mode is from **P09...40 °C** in place of 5...40 °C  
– The setting range in heating mode is from **5...P10 °C** in place of 5...40 °C  
• For heating **and** cooling applications (e.g. single duct with el. heater):  
– **P09** is the setpoint for cooling and **P10** the setpoint for heating  
– The setpoint can no longer be adjusted via the rotary knob

Examples	Single duct Heating OR cooling	Single duct & el. heater Heating AND cooling
P09 < P10	 <p>5°C      18°C      25°C      40°C P09      P10</p> <p>Cooling setpoint adjustable 18...25 °C Heating setpoint adjustable 18...25 °C</p>	 <p>5°C      18°C      25°C      40°C P09      P10</p> <p>Cooling setpoint adjustable 18...25 °C Heating setpoint adjustable 18...25 °C</p>
P09 ≥ P10	 <p>5°C      21°C      25°C      40°C P10      P09</p> <p>Cooling setpoint adjustable 25...40 °C Heating setpoint adjustable 5...21 °C</p>	<p>Cooling fixed = 25 °C (P09) Heating fixed = 21 °C (P10)</p>

**Economy mode** ☰ Use control parameters P11 and P12 to adjust the Economy mode setpoints. The heating setpoint is factory-set to **15 °C**, and the cooling setpoint to **30 °C**.

**Protection mode** 🏠 Use control parameters P65 and P66 to adjust the Protection mode setpoints. The heating setpoint is factory-set to **8 °C** (frost protection) and to **OFF** for cooling.

**Caution** 

If a setpoint (Economy or Protection) is set to OFF, the thermostat does not control the room temperature in the corresponding mode (heating or cooling). This means no protective heating or cooling function and thus risk of frost in heating mode or risk of overtemperature in cooling mode!

The Economy setpoints are accessible at the service level (P11, P12); the Protection setpoints at the expert level (P65, P66).

### 3.3.2 Setting and adjusting setpoints

Room temperature setpoints can be

- set during commissioning
- adjusted during runtime



**Comfort basic setpoint**  
**Comfort setpoint**

The source can be


- the local HMI
- a tool
- a central control unit

The thermostat stores the setpoints

- in EEPROM in the form of parameters
- in the runtime memory

The table below shows the interrelations:

Setpoint setting			Stored in EEPROM of thermostat
Commissioning – HMI – Tool download	Input LTE mode	Input S-mode	
Comfort basic setpoint	Setpoints Heating	Comfort basic setpoint	P08 Comfort basic setpoint
Dead zone Comfort 1)	Setpoints Cooling		P33 Dead zone Comfort 1)
Setpoint Economy Heating	Setpoints Heating		P11 Economy Heating
Setpoint Economy Cooling	Setpoints Cooling		P12 Economy Cooling
Setpoint Protection Heating			P65 Protection Heating
Setpoint Protection Cooling			P66 Protection Cooling





## Current setpoint

### General notes:

- 1) Only required for heating AND cooling applications (see section 3.6.6)
- 2) **The shift is added** to the local shift (LTE mode only)
- 3) **The last intervention wins**, either S-Mode input or local operation

The current setpoint (used by the thermostat for temperature control) is available on the bus for use in the central control unit.

### Notes on setpoint adjustment (LTE mode with Synco only)

- The supported communication objects are different in LTE mode and S-mode
- Changes via the local HMI or via KNX have the same priority (last always wins)
- Adjusting the Comfort basic setpoint will reset the runtime Comfort setpoint to the basic setpoint

- Central setpoint shift is used for summer / winter compensation in particular
- Setpoint shift does not affect the setpoints stored in parameters P08, P11, P12, P33
- Local shift and central shift are added together
- Applies only to Comfort and Economy setpoints; Protection setpoints are not shifted centrally
- The resulting (current) setpoint heating and cooling is limited by the Protection setpoint; if Protection setpoint is OFF, then minimum 5 °C and maximum 40 °C are used
- The resulting setpoints for cooling and heating of the same operating mode have a minimum distance of 0.5 K between them
- The result of local and central shift, together with the room operating mode, is used by the thermostat for temperature control (current setpoint)

## 3.4 Applications overview

The thermostats support the following applications, which can be configured using the DIP switches inside the front panel of the unit or a commissioning tool.

All DIP switches need to be set to OFF (remote configuration, factory setting) to select an application via commissioning tool. In this case the output signal type needs to be set in ACS as well.

The tool offers the applications printed in bold text (basic applications).

Application and output signal	Diagram	DIP switches
<b>Remote configuration</b> via commissioning tool (factory setting) <ul style="list-style-type: none"> <li>• Synco ACS</li> <li>• ETS3 professional <i>(Parameter and application download with ETS3 will be implemented later)</i></li> </ul>		
<b>Single duct</b> <ul style="list-style-type: none"> <li>• Single duct heating or cooling DC 0...10 V output signal normal</li> <li>• Single duct heating or cooling DC 10...0 V output signal inverted</li> </ul>		 
<b>Single duct with electric heater</b> <ul style="list-style-type: none"> <li>• Single duct heating and cooling, with electrical heater DC 0...10 V output signal normal</li> <li>• Single duct heating and cooling, with electrical heater DC 10...0 V output signal inverted</li> </ul>		 

## 3.5 Additional functions

### Air heating / cooling changeover



Supply air temperature

The supply air temperature sent by the primary controller indicates whether cool or warm air is supplied.

The controller determines the necessity to open or close the air damper according to the supply air temperature, the room temperature setpoint and the current room temperature.

If no Supply air temperature is available via bus, then the air changeover is cooling per default.

With application "Single duct", the changeover can also be accomplished via a local multifunctional input X1/X2 (parameter P38, P40).

*Only one input source must be used, either local input X1/X2 or KNX, and parameter "control sequence" must be set to automatic heating / cooling changeover (parameter P01 = 3).*

Functionality of the local changeover input see below.


See also section 3.8 "Multifunctional input".

### Automatic heating / cooling changeover via changeover sensor

If a cable temperature sensor (QAH11.1 + ARG86.3) is connected to X1 / X2, and parameter P38 / P40 is = 2, the water or supply air temperature acquired by the sensor is used to change over from heating to cooling mode, or vice versa. When the water / air temperature is above 28 °C (parameter P37), the thermostat changes over to heating mode, and to cooling mode when below 16 °C (parameter P36).


If the water / air temperature is between the 2 changeover points immediately after power-up, the thermostat starts in heating mode.

The water / air temperature is acquired at 30-second intervals and the operating state is updated accordingly.



### Changeover switch

The QAH11.1 cable temperature sensor for automatic heating / cooling changeover can be replaced by an external switch for manual, remote changeover:



The sensor or switch can be connected to input terminal X2 or X1, depending on the commissioning of the inputs (P38, P40).

See also section 3.8 "Multifunctional input".

<b>Manual heating / cooling changeover</b>	If manual heating / cooling changeover is commissioned (P01 = 2), then heating / cooling mode cannot be changed via bus / changeover sensor / switch; it will remain in the last mode as selected locally via button.
<b>External / return air temperature sensor</b>	The thermostat acquires the room temperature via built-in sensor, external room temperature sensor (QAA32), or external return air temperature sensor (QAH11.1), connected to multifunctional input X1 or X2. Inputs X1 or X2 must be commissioned accordingly. See section 3.8 “Multifunctional input”.
<b>Dew point monitoring</b>	Dew point monitoring is essential to prevent condensation on the chilled ceiling. It helps avoid associated damage to the building. A dew point sensor with a potential-free contact is connected to multifunctional input X1 or X2. If there is condensation, the cooling valve is fully closed until no more condensation is detected, and the cooling output is disabled temporarily.  The condensation symbol “ $\Delta$ ” is displayed during temporary override and the fault “Condensation in room” will be sent via bus. The input must be commissioned accordingly (P38, P40). See section 3.8 “Multifunctional input”.
<b>Button lock</b>	If the “Button lock” function is enabled by parameter P14, the buttons will be locked or unlocked by pressing the right button for 3 seconds. If “Auto lock” is configured, the thermostat will automatically lock the buttons 10 seconds after the last adjustment.

## 3.6 Control sequences

### 3.6.1 Sequences overview (setting via parameter P01)

The mode of the air control sequence can be set via **parameter P01**.  
It is only available with application "Single duct"

In all applications the changeover of the air sequence can be done via supply air temperature sent by the primary controller.

The available sequences depend on the application:

Parameter	P01 = 0	P01 = 1	P01 = 2	P01 = 3	c/o signal on X1 / X2 / D1	c/o signal via bus	Supply air temp. via bus
Sequence							
Available for basic application: ↓	Heating	Cooling	Manually select heating or cooling sequence	Automatic heating / cooling changeover			
Single duct	✓	✓	✓	✓	✓ <sup>1)</sup>		✓ <sup>1)</sup>
Single duct & el heater	-	-	-	-			✓ <sup>1)</sup>

Notes: 1) Changeover air

For the relation between setpoints and sequences, see section 3.6.6.



## Application mode

### 3.6.2 Application mode

The behavior of the thermostat can be influenced by a building automation and control system (BACS) via bus with the command “Application mode”. With this signal, cooling and/or heating activity can be enabled or disabled. Application mode is supported in LTE mode and S-mode. The RDU KNX thermostats support the following commands:

#	Application mode	Description	Control sequence enabled
0	Auto	Thermostat automatically changes between heating and cooling	Heating and/or cooling
1	Heat	Thermostat is only allowed to heat	Heating only
2	Morning warm-up	If “Morning warm-up” is received, the room should be heated up as fast as possible (if necessary). The thermostat will only allow heating	Heating only
3	Cool	Thermostat is only allowed to provide cooling	Cooling only
4	Night purge	If “Night purge” is received, the room should be aired with cool outside air if necessary. The thermostat will open the damper and does not heat/cool with the coils or the electric heater. Function will be terminated by any operation on the thermostat.	Open damper fully if night purge condition is valid <sup>1)</sup>
5	Pre-cool	If “Pre-cool” is received, the room should be cooled down as fast as possible (if necessary). The thermostat will only allow cooling	Cooling only
6	Off	Thermostat is not controlling the outputs, which means all outputs go to off or 0%	Neither heating nor cooling
8	Emergency heat	The thermostat should heat as much as possible. The thermostat will only allow heating	Heating only
9	Fan only	All control outputs are set to 0% and only the fan is set to high speed or damper fully opened respectively. Function will be terminated by any operation on the thermostat	Open damper fully

With all other commands, the thermostat behaves like in Auto mode, i.e. heating or cooling according to demand.

1) Conditions for “Night purge” function:

- Current room temperature > Comfort cooling setpoint
- If supply air temperature via KNX is available:  
Supply air temperature < current room temperature



The state (heating or cooling) of the thermostat can be monitored with the ACS700 tool (diagnostic value "Control sequence"). The last active mode is displayed when the thermostat is in the dead zone or temperature control is disabled.

### Heating OR cooling

With a single-duct application, the control sequence state is determined by the application mode (see section 3.6.2) and by the state of the heating / cooling changeover signal (via local sensor or bus), or fixed according to the selected control sequence (P01 = heating (0) / cooling (1)).


Application mode (via bus)	State changeover / continuous heating or cooling	Control sequence state
Auto (0)	Heating	Heating
	Cooling	Cooling
Heat (1), (2), (8)	Heating	Heating
	Cooling	<b>Heating</b>
Cool (3), (5)	Heating	<b>Cooling</b>
	Cooling	Cooling
Night purge (4), Fan only (9)	Heating	Heating
	Cooling	Cooling

### Heating AND cooling

With applications "Single duct with electric heater / radiator / heating / cooling coil", the control sequence state depends on the application mode and on the heating / cooling demand.

Application Mode (via bus)	Heating / cooling demand	Control sequence state
Auto (0)	Heating	Heating
	No demand	Heating / cooling depending on last active sequence
	Cooling	Cooling
Heat (1), (2), (8)	Heating	Heating
	No demand	<b>Heating</b>
	Cooling	<b>Heating</b>
Cool (3), (5)	Heating	<b>Cooling</b>
	No demand	<b>Cooling</b>
	Cooling	Cooling
Night purge (4), Fan only (9)	No temperature control active	Heating / cooling depending on last active sequence

The value of the output as a function of the room temperature is shown in the following diagram in case of a heating and cooling system:




### 3.6.3 Minimum and maximum air volume

The factory setting for minimum and maximum air volume is 0 / 100% respectively. These values can be changed using parameters P63 / P64.


If  $V_{min}$  is greater than 0, a minimum air flow of  $V_{min}$  is assured in Comfort and Economy mode.

In Protection (or Economy mode with setpoint = OFF),  $V_{min}$  is fixed to 0.

Comfort or Economy mode



Protection mode:  $V_{min}$  always = 0



### 3.6.4 Single-duct

On single-duct applications, the thermostat controls an actuator (air damper, VAV system, valve etc.)...

- in heating / cooling mode with changeover (automatic or manual),
- heating only mode,
- or cooling only mode.


Cooling only is factory-set (P01=1).

The output signal for the air flow can be limited to a minimum and maximum value if required (see section 3.5 "Additional features").


#### Modulating control: DC 0...10 V

The diagrams below show the control sequence for modulating PI control.


Heating only (P01 = 0)



Cooling only (P01 = 1)



Changeover (P01 = 2, 3)



T[°C]	Room temperature
w	Room temperature setpoint
Y	Control command "Actuator"

XpH	Proportional band "Heating"
XpC	Proportional band "Cooling"
Vmin	Min. limitation for output
Vmax	Max. limitation for output

Note: The diagrams show the PI controller's proportional part only.

#### Setting the sequence and the control outputs

Refer to sections 3.4 "Applications", 3.6.1 "Sequences", and 3.7 "Outputs".

### 3.6.5 Single-duct with electric heater

---

#### Caution

General rule: In case of insufficient air flow, the thermostat cannot protect the electrical heater against overtemperature. Therefore the electric heater MUST feature a separate safety device (thermal cutout).

On single-duct applications with electrical heater, the thermostat controls a valve plus an auxiliary electrical heater. Parameter P01 is not available.

The output signal for the air flow can be limited to a minimum and maximum value if required using parameters P63 and P64. With application "Single-duct with electric heater", the min. value of P63 is overridden, so that the air flow never drops below 10 % while the electric heater is ON.

Electrical heating, active in cooling mode

The air flow starts to rise depending on the acquired room temperature, the current supply air temperature (if available) and the setpoint.

The electrical heater receives an **ON** command when the acquired room temperature drops below setpoint (= setpoint for electrical heater).

Digital input "Enable electrical heater"

Remote enabling / disabling of the electric heater is possible via input X1 or X2 for tariff regulations, energy savings, etc.

Input X1 or X2 must be commissioned accordingly (parameters P38, P40).

See section 3.8 "Multifunctional input".

  
Enable electric heater

The electric heater can also be enabled / disabled via bus.

Note If "Enable electric heater" input is used via bus, then the function **must not** be assigned to a local input X1 or X2.

On start-up of the controller and if the primary controller sends the information that the primary fan is off, the thermostat disables the electric heater, see section 3.10.9.

"Fan overrun time"


To avoid overheating of an electric heater when switched off, the air flow signal of Vmin must be maintained for a preset "fan overrun time" (P54, factory setting 60sec).

In conjunction with a Syncro primary controller it will be assured that the primary fan keeps running during the fan overrun time.


See also section 3.10.10.

## Sequences

### ON/OFF electrical heater



Without a valid bus signal for changeover air, the air volume is only increased for cooling:



Note: The diagrams only show the PI thermostat's proportional part.

### Setting the sequence and the control outputs

Refer to sections 3.4 "Applications", 3.6.1 "Sequences", and 3.7 "Outputs".

### 3.6.6 Setpoints and sequences

**Single duct / single duct with heating / cooling coil**


- Comfort setpoint (W) is in the currently active heating or cooling sequence

**Single duct with el. heater / radiator / floor heating**

- Comfort setpoint (W) is in the heating sequence

**Changeover air**


- If the supply air temperature is available (via KNX), the air flow may also increase when the room temperature is below the heating setpoint
- If no supply air temperature is available, sequence for air flow control is Cooling only



**Economy, Protection**

The setpoints for Economy and Protection mode are below the Comfort setpoints (heating) and above the Comfort setpoints (cooling).

They can be set via parameters P11, P12 (Economy mode) and P65, P66 (Protection mode). .



3181D127

Application	Comfort mode		Economy / Protection mode	
	Heating	Cooling	Heating	Cooling
Single duct				
Heating and Cooling		Heating and Cooling		
Single duct with el. heate				

W = setpoint in Comfort mode

W<sub>HeatEco/Prot</sub> = setpoint heating in Economy or Protection mode

W<sub>CoolEco/Prot</sub> = setpoint cooling in Economy or Protection mode

Y = air / water sequence

T = room temperature

The dead zone can be adjusted via parameter P33.

## 3.7 Control outputs

### 3.7.1 Overview

---

#### Overview of control outputs

Different control output signals are available. They need to be defined during commissioning (see below).

Control output	ON/OFF	3-position	DC 0...10 V
Product no.			
RDU340	Y21	--	Y10

#### DC 0..10 V control signal

The demand calculated by the PI control from the current room temperature and setpoint is provided to the damper actuator as a continuous DC 0...10 V signal via output Y10.

#### Electrical heater control signal (2-position)

The electrical heater receives an **ON** command via the auxiliary heating control output Y21:

1. When the acquired room temperature is below “setpoint for electric heater”.
2. When the electrical heater has been switched off for more than 1 minute.

The **OFF** command for the electrical heater is output:

1. When the acquired room temperature is above the setpoint (electric heater).
2. When the electrical heater has been switched on for more than 1 minute.

**Caution** 

A safety thermostat (to prevent overheating) must be provided externally.

### 3.7.2 Control outputs configuration (setting via DIP switches or tool)

---

Use DIP switch #3 on the inner side of the front panel to commission the signal type of Y10 prior to snapping it to the base.

DIP switch number	3
DC 0...10 V output signal normal (factory setting)	OFF
DC 0...10 V output signal inverted (DC 10...0 V)	ON

If the application is configured via tool (DIP switches #1 and #2 = OFF), then the signal type of Y10 must also be configured via tool.

Note: During startup, the controller reloads the control parameter factory settings after each DIP switch settings change.

## 3.8 Multifunctional input, digital input

The thermostat has 2 multifunctional inputs X1 and X2

An NTC type sensor like the QAH11.1 (AI, analog input) or a switch (DI, digital input) can be connected to the input terminals. The functionality of the inputs can be configured via parameters P38 + P39 for X1, P40 + P41 for X2.



The current temperature or state of the inputs X1/X2 is available on bus for monitoring purposes.

The parameters can be set to the following values:

#	Function of input	Description	Type X1/X2
0	Not used	No function.	--
1	External / return air temperature	Sensor input for external room temperature sensor or return air temperature sensor to acquire the current room temperature, or floor heating temperature sensor to limit the heating output.	AI
2	Heating / cooling changeover	<p>Sensor input for "Automatic heating / cooling change-over" function. A switch can also be connected rather than a sensor (switch closed = cooling, see section 3.5).</p> <p>With single-duct applications, the input changes over the air sequence.</p> <p>Heating / cooling changeover is also possible via bus. In this case, the function must not be assigned to any local input X1, X2, D1. See also section 3.5.</p> <p>Diagnostic value 0 °C is displayed for closed contact / 100 °C for open contact, if a switch is connected.</p>	AI / DI
3	Operating mode switchover	<p>Digital input to switch over the operating mode to Economy. If the operating mode switchover contact is active, user operations are ineffective and "OFF" is displayed.</p> <p>Operating mode switchover is also possible via bus. In this case, the function must not be assigned to any local input X1, X2. See also section 3.2.</p>	DI
4	Dew point monitor	Digital input for a dew point sensor to detect condensation. Cooling is stopped if condensation occurs.	DI
5	Enable electric heater	<p>Digital input to enable / disable the electric heater via remote control.</p> <p>Enable electric heater is also possible via bus. In this case, the function must not be assigned to any local input X1, X2. See also section 3.6.</p>	DI



Supply air temperature



Window state



Enable electric heater

#	Function of input	Description	Type X1/X2
6	Fault	Digital input to signal an external fault (example: dirty air filter). If the input is active, "ALx" is displayed and a fault is sent on the bus. See also section 3.10.11. (Alarm x, with x = 1 for X1, x = 2 for X2). <b>Note:</b> Fault displays have no impact on the thermostat's operation. They merely represent a visual signal.	DI
7	Monitor input (Digital)	Digital input to monitor the state of an external switch via bus.	DI
8	Monitor input (Temperature)	Sensor input to monitor the state of an external sensor (e.g. QAH11.1) via bus.	AI

- Operational action can be changed between normally open (NO) and normally closed (NC) via parameter P39, P41.
- Each input X1, X2 must be configured with a different function (1...5).  
Exception: 1 or 2 inputs can be configured as fault (6) or monitor input (7,8)
- X1 is factory-set to "Operating mode switchover" (3), X2 to "External sensor" (1)

For more detailed information, refer to section 3.4 "Applications".

## 3.9 Handling faults

---

### Temperature out of range

When the room temperature is outside the measuring range, i.e. above 49 °C or below 0 °C, the limiting temperatures blink, e.g. “0 °C” or “49 °C”.

In addition, the heating output is activated if the current setpoint is not set to “OFF”, the thermostat is in heating mode and the temperature is below 0 °C.

For all other cases, no output is activated.

The thermostat resumes Comfort mode after the temperature returns to within the measuring range.



For fault status messages on the bus, see section 3.10.11.

## 3.10 KNX communications

---

The RDU KNX thermostats support communications as per the KNX specification.

S-mode Standard mode; engineering via group addresses.

LTE mode Logical Tag Extended mode, for easy engineering, is used in conjunction with Synco.

### 3.10.1 S-mode

---

This mode corresponds to KNX communications.

Connections are established via ETS3 Professional by assigning communication objects to group addresses.

### 3.10.2 LTE mode

---


LTE mode was specifically designed to simplify engineering. Unlike with S-mode, there is no need to create the individual connections (group addresses) in the tool. The devices autonomously establish connections.

### Definitions

To make this possible, the following circumstances are predefined:

- Every device or subdevice is located within a zone
- Every data point (input or output) is assigned to a zone
- Every data point (input or output) has a precisely defined "name"

Whenever an output and an input with the same "name" are located in the same zone, a connection is established automatically, as shown in the following diagram.



## Engineering and commissioning

- For a detailed description of KNX (topology, bus supply, function and setting of LTE zones, filter tables, etc.), see "Communication via the KNX bus for Synco 700, 900 and RXB/RXL, Basic Documentation" [6]
- LTE mode data points and settings are described in the Synco Application Manual [12]
- To engineer and commission a specific system, use the Synco700 planning and commissioning protocol (XLS table in HIT, [7])

### 3.10.3 Zone addressing in LTE mode (in conjunction with Synco)

In cases where RDU KNX room thermostats are used in LTE mode (e.g. in conjunction with Synco), zone addresses need to be allocated.

The following zone address must be defined together with the Synco devices at the planning stage depending on the application.

Short description	Factory setting	Parameter
Geographical zone (apartment)	--- (out of service)	P82
Geographical zone (room)	1	P83
Air distribution zone	--- (out of service)	P87

Note: "Subzone" of "Geographical zone" is fix 1 (not adjustable)


The device will send and receive LTE communication signals only if the zone address is valid (not OSV = out of service).

The zones to be defined are as follows:

<b>Geographical zone (space zone)</b> (Apartment . Room . Subzone) Apartment = ---, 1...126 Room = ---, 1...63 Subzone = fix 1	<p>Zone in which an RDU KNX thermostat is physically located. Other room-specific devices may also be located in this zone.</p> <p>Information exchanged in this zone is related specifically to the device like operating mode, setpoints, room temperature, etc.</p> <p>The designations "Apartment", "Room" and "Subzone" do not need to be taken literally. For example, Apartment can be used to refer to a group of rooms, floor or section of a building. "Room", however, really does refer to a room.</p> <p>Subzone is not used for HVAC devices. It is more relevant to other disciplines, such as lighting. Subzone is fix at "1" and not visible.</p> <p>The time switch information is expected from the same zone where the thermostat is located (Residential).</p> <p>If no time switch information is received from the same zone, the thermostat will use the information received from the same apartment but with room "1" A.1.1 (Office).</p>
<b>Example: Commercial building</b>  In a commercial building, the time switch information is sent by the RMB975 central control unit. The zones are divided in so called "Room groups" (e.g. 1...4), where each "Room group" can have an individual schedule. A room thermostat in the same "Room group" need to have the same Apartment Address.  Legend: D = device address (P81) G = geographical zone (P82, P83) (Apartment.Room.Subzone)	
<b>Air distribution zone</b>  Zone = ---, 1...31	This Distribution zone is for air applications (VAV, CAV). Information related specifically to the air handling system is exchanged within this zone (e.g. air demand). This zone also includes a Sync device to process the information (e.g. RMU7xx).
<b>Outside temperature zone</b>  Zone = fix 1	Outside temperature received in outside temperature zone 1 will be / can be displayed on the room thermostat when commissioned accordingly (parameter P07 = 2).

### 3.10.4 Example of heating and cooling demand zone

The building is equipped with Synco controls on the generation side and RDU / RDG thermostats on the room side.



#### Explanation relating to the illustration

In the case of a typical application, the individual RDU / RDG room thermostats – when used with the RMB975 central control unit – signal their heat demand directly to the primary controller (in the above example to the RMH760).

(1) and (2) designate the numbers of the distribution zone.

#### Notes:

- This type of application can analogously be applied to refrigeration distribution zones
- If no 2-pipe fan coil is used, heat and refrigeration demand signals are sent simultaneously to the primary plant

### 3.10.5 Send heartbeat and receive timeout

---

In a KNX network, S-mode and LTE mode communication objects can be exchanged between individual devices. The *Receive timeout* defines the period of time within which all the communication objects requested from a device must have been received at least once. If a communication object is not received within this period, a predefined value is used.

Similarly, the *Send heartbeat* defines the period of time within which all the communication objects requested must be transmitted at least once.

#### LTE mode / S-mode

Fixed times are specified as follows:

- Receive timeout: 31 minutes
- Send heartbeat: 15 minutes

#### Reducing the bus load

Individual zones can also be disabled (out of service) via control parameter if they are not being used. In disabled zones, the LTE signal will no longer be periodically sent, and will therefore reduce bus load.

### 3.10.6 Startup

---

#### Startup response

The application is restarted after every reset, so that all the connected motorized valve actuators are synchronized (see "Control outputs", 3.7).

#### Startup delay

After a reset, it takes up to 5 minutes for all the connected room thermostats to restart. This is designed to avoid overloading the network when restarting. At the same time, it reduces the load on the KNX network, as not all thermostats transmit data at the same time. The delay ( $T_{WaitDevice}$ ) is determined by the thermostat's device address. After the delay, the device starts to send.

### 3.10.7 Heating demand

---



Heating output primary  
Cooling output primary

In S-mode, the current state signal of the control output (e. heater) is available.

### 3.10.8 Air demand

---

In conjunction with Synco, the air demand from each room is transmitted to the BACS to provide the required air volume.



In S-mode, the current state signal of the damper is available.

### 3.10.9 Electric heater interlock by supply air controller (LTE mode only)

---

To avoid overheating of an electric heater, sufficient flow of supply air must be guaranteed. The thermostat features the function "Interlock of el. heater via supply air controller", which is active when a supply air controller (e.g. Synco RMU7xx) is used in the system. The supply fan controller sends the fan status (StatusSATC) to the thermostat when the supply fan is running, after which the el. heater is allowed to turn on if there is a call for heat.

When the supply fan is not running, then the el. heater keeps turned off, even though there is a demand for heat.

The fan symbol  is displayed, when the supply fan is on.

- Notes
- Electric heater enable via local input X1 / X2 or via KNX will override any release by this interlock function and vice versa (last intervention wins).
  - After power-up of the thermostat the electric heater is completely disabled for at least 5 minutes or until a supply air controller is detected. If no supply fan controller is in the system, the el. heater is allowed to turn on if there is a demand for heat.
  - The fan information is broadcast every 15 minutes or on change of value. If no value is received any more, the thermostat will disable the interlock function after a timeout of 31 minutes.

**Caution** 

General rule: In case of insufficient air flow, the thermostat cannot protect the electrical heater against overtemperature. Therefore the electric heater MUST feature a separate safety device (thermal cutout).

### 3.10.10 Primary fan overrun after switching off the electric heater

---

To avoid overheating of an electric heater after it has been switched off, the air flow must be maintained for a while.

In conjunction with a supply air controller (e.g. Synco RMU7xx) this will be automatically assured by exchanging the necessary information. The supply fan controller will only switch off the supply fan once all el. heaters are cooled off.

Note: The cool off time of the el. heater can be adjusted for each el. heater via parameter "fan overrun time" (P54, factory setting 60sec).

**Caution** 

General rule: In case of insufficient air flow, the thermostat cannot protect the electrical heater against overtemperature. Therefore the electric heater MUST feature a separate safety device (thermal cutout).

### 3.10.11 Fault function on KNX

If a fault occurs (e.g. digital fault input, dew point, communication configuration, etc.) then a fault will be sent on the bus.

An RDU thermostat listens on the bus and sends its fault when the fault has the highest alarm priority. This ensures that the management station does not miss any alarms.

If alarms occur at the same time, the alarm with the highest priority will be first displayed and sent on the bus.



Fault transmission is different in LTE mode and S-mode:

S-mode	LTE mode
Fault state	Alarm info (error code + internal information)
Fault information (internal information)	Alarm text (default text can be edited with ACS700 tool)

The table below shows the error code and default alarm texts.

Prio	Fault	Fault information on bus			
		Thermostat	Error code	Default fault text	Text adjustable *)
-	No fault	---	0	No fault	✓
1	Bus power supply**)	⚠ bus	5000	No bus power supply	---
2	Device address error	⚠ Addr	6001	>1 id device address	---
3	Condensation	⚠ ⚡	4930	Condensation in the room	✓
4	External fault input X1	⚠ AL1	9001	Fault input 1	✓
5	External fault input X2	⚠ AL2	9002	Fault input 2	✓

\*) Default alarm texts are stored in the thermostat's non-volatile memory and can be adjusted using the ACS700 commissioning tool

\*\*) This error will not be sent on bus (because there is no bus!)

#### Priority of alarms

- Priority order is #1...5
- External faults #4...5: If faults are active, the display will show AL1, AL2, alternating. On the bus, only the fault with the highest priority will be sent



#### Fault transmission

A supervisor alarm system may command the thermostat to stop sending faults to the bus via the communication object "Fault transmission" (disable / enable). This has no impact on the local display of faults.

After a timeout of 48 hours, the sending of faults will automatically be enabled again.

### 3.10.12 Emergency control (LTE Mode only)

---

In case of smoke or fire the damper can be overridden via KNX.

The necessary information is provided by the function block “HVAC Emergency Mode”

The table below describes the behavior of the controller output.

#	Datapoint value	Damper
0	Normal	Normal operation
1	EmergPressure	Fully open
2	EmergDepressure	Fully closed
3	EmergPurge	Fully open
4	EmergShutdown	Fully closed
5	EmergFire	Fully closed

Emergency signals have highest priority and command the control output accordingly. Any ongoing function like fan-overrun etc. will be stopped immediately.

The priority is as follows:

1. Smoke (Emergency 1..4)
2. Fire (Emergency 5)
3. Fan overrun (Emergency 0 and el heater fan overrun function is active)
4. Normal operation (Emergency 0 and operation by operating mode button)

## 3.11 Communication objects (S-mode)

### 3.11.1 Overview

Page	Object # and name	Thermostat	Object # and name	Page
12	1 System time	→	21 Room temperature	12
12	3 Time of day	→	16 Room operating mode: State <sup>1)</sup>	13
12	38 Outside temperature	→	24 Room temperature: Current setpoint	21
14	12 Room operating mode: Time switch <sup>1)</sup>	→	32/33 X1 (temperature / digital)	35
14	7 Room operating mode: Preselection <sup>1)</sup>	↔	34/35 X2 (temperature / digital)	35
13, 15, 34	20 Room operating mode: Window state	→	25 Control output VAV	40
20	22 Room temperature: Comfort basic setpoint	→	26 Heating output primary <sup>2)</sup>	40
20	23 Room temperature: Comfort setpoint	↔		
26	31 Application mode	→		
34	20 Enable electric heater	→		
23, 34	30 Supply air temperature	→		
42	6 Fault transmission	→	5 Fault state	24, 42
		→	4 Fault information	24, 35, 42



Input communication object



Output communication object



Input & output communication object

1) 8-bit and 1-bit object available, selectable via parameter in ETS3

2) Availability depending on selected application / function

### 3.11.2 Description of communication objects

Obj	Object name	Function	Type/ length	Flags
1	<b>System time</b>	Time and date	19.001 8 Byte	CWU
System time for display on the room thermostat. See parameter P07 (3 or 4)				
3	<b>Time of day</b>	Time and date	10.001 3 Byte	CWU
Another object for receiving the time of day for display on the room thermostat. See parameter P07 (3 or 4)				
4	<b>Fault information</b>	Alarm Info	219.001 6 Byte	CT
Common alarm output. If an alarm occurs, the alarm number is transmitted				
5	<b>Fault state</b>	Faulty / normal	1.005 1 bit	CT
Common alarm output. If an alarm occurs, the alarm flag is set				
6	<b>Fault transmission</b>	Enable / disable	1.003 1 bit	CWU
A supervisor alarm system can disable the broadcasting of alarms by the devices. This has no impact on the local display of alarms. After a timeout of 48 hours, the sending of faults will automatically be enabled again.				
7	<b>Room operating mode: Preselection</b>	Auto Comfort PreComf. Economy Protection	20.102 1 Byte	CWTU
Controls the room operating mode selection of the thermostat via bus.  The command can also be submitted as four 1-bit communication objects (8...11). The last interaction wins – either from local operating mode button or via bus.  Note: The thermostat will transform Precomfort either into Economy or Comfort (selectable via P88).				
8	<b>Operating mode: Preselection</b>	Trigger	1.017 1 bit	CW
9	<b>Auto</b>			
10	<b>Comf</b>			
11	<b>Eco</b>			
	<b>Prot</b>			
Switch room operating mode to either Auto, Comfort, Economy or Protection.  The last interaction wins – either from the local operating mode button or via bus.				
12	<b>Room operating mode: Time switch</b>	Comfort Economy PreComf. Protection	20.102 1 Byte	CWU
This information is provided by a central time switch or a supervisor and defines the actual HVAC operating mode.  The command can also be submitted via three 1-bit communication objects (13...15).  Protection has the highest priority and cannot be overridden.  Note: The thermostat will transform Precomfort either into Economy or Comfort (selectable P88).				
13	<b>Time switch</b>	Trigger	1.017 1 bit	CW
14	<b>Comfort</b>			
15	<b>Economy</b>			
	<b>Protection</b>			
Switch the HVAC mode to either Comfort, Economy or Protection mode.				

Obj	Object name	Function	Type/ length	Flags
16	<b>Room operating mode: State</b>	Comfort Economy Protection	20.102 1 Byte	CRT
Effective room operating mode used by the thermostat (considering time switch, user selection, window contact, etc.) This state information is available via one 8-bit enumeration or three 1-bit communication objects (17...19). Note: The thermostat does not support Precomfort.				
17	<b>Room operating mode:</b>	ON OFF	1.002 1 bit	CT
18	<b>State Comfort</b>			
19	<b>State Economy</b>			
	<b>State Protection</b>			
Corresponding communication object sends "True"				
20	<b>Window state</b>	Open Closed	1.019 1 bit	CWU
The thermostat is set to Economy mode if value "1" (open) is received. It switches back to the previous mode when the value is "0" (closed).  "Window state" is sent e.g. by a KNX switch or a KNX presence detector. It has the same effect as the local operating mode switchover contact X1, X2 (parameter P38, P40).  <i>Only one input source must be used, either local input X1/X2 or KNX bus.</i>				
21	<b>Room temperature</b>	Temp. value	9.001 2 Bytes	CRT
The value of the room temperature measured via built-in or external sensor is available via this communication object.				
22	<b>Room temperature: Comfort basic setpoint</b>	Temp. value	9.001 2 Bytes	CWU
If function "Temporary setpoint" is enabled via parameter P69, then after an operating mode change, the setpoint adjustments made by the user and via communication object 23 will be dismissed and the thermostat will be reset to the Comfort basic setpoint.  Note: Setpoints that have been changed via the local HMI may be overwritten during a system startup from a central master controller, e.g. RMB795.				
<i>The Comfort basic setpoint is stored in EEPROM (see section 3.3.2). → The service life of the EEPROM depends on the number of write cycles. Never write this communication object cyclically!</i>				
23	<b>Room temperature: Comfort setpoint</b>	Temp. value	9.001 2 Bytes	CWTU
Communication object used to shift the setpoint used by the thermostat (see section 3.3.2). Same priority as local setpoint shift on the thermostat. The last intervention wins.  Note: The Comfort basic setpoint (object 22) will not be changed.				
24	<b>Room temperature: Current setpoint</b>	Temp. value	9.001 2 Bytes	CRT
Current setpoint, including shift, compensation, etc., used by the thermostat for temperature control				
25	<b>Control output VAV</b>	0...100% 8 bit	5.001 8 bit	CRT
Indicates the position of the air damper. E.g. single duct				
26	<b>Heating output primary</b>	0...100% 8 bit	5.001 8 bit	CRT
Indicates the position of the heating actuator of the auxiliary heating. E.g. single duct with electric heater application: Output of the electric heater.				

Obj	Object name	Function	Type/ length	Flags
28	<b>Enable electric heater</b>	Enable / disable	1.003 1 bit	CWU
An electric heater can be disabled with this communication object (e.g. to meet tariff regulations).				
The same function is also available via local multifunctional input X1/X2 (parameter P38, P40).				
<i>Only one input source must be used, either local input X1/X2 or KNX bus.</i>				
30	<b>Supply air temperature</b>	Temp. value	9.001 2 Byte	CWU
The supply air temperature sent by the supply air controller indicates whether cold or hot air is supplied (for VAV changeover). The controller determines the necessity to open or close the air damper according to the supply air temperature, the room temperature setpoint, and the current room temperature.				
The same function is also available via local multifunctional input X1/D1 (parameter P38, P42).				
<i>Only one input source must be used, either local input X1/X2/D1 or KNX bus.</i>				
31	<b>Application mode</b>	HVAC control mode	20.105 8 bit	CWU
0	Auto (default)	Heating and/or cooling		
1	Heat	Heating only		
2	Morning warmup*	Heating only		
3	Cool	Cooling only		
4	Night purge	Open damper fully		
5	Precool*	Cooling only		
6	OFF	Neither heating nor cooling		
8	Emergency heat*	Heating only		
9	Fan only	Open damper fully (= night purge)		

\* Function handled like Heat (1) or Cool (3)

Obj	Object name	Function	Type/ length	Flags
32	<b>X1: Temperature</b>	Temp.	9.001	CRT
34	<b>X2: Temperature</b>	value	2 Byte	
Indicates the values of the temperature sensors connected to the local inputs X1 / X2				
33	<b>X1: Digital</b>	ON	1.001	CRT
35	<b>X2: Digital</b>	OFF	1 bit	
Indicates the status of the digital inputs (adjusted by parameters P39/P41) including considering of operating action				
38	<b>Outside temperature</b>	Temp. value	9.001 2 Byte	CWU
The outside temperature measured by a KNX sensor can be displayed on the thermostat, if parameter P07 "Additional user information" is set = 2 (outside temperature).				

## 3.12 Control parameters

A number of control parameters can be readjusted to optimize control performance. This can be done on the thermostat via HMI or via commissioning / operating tool. These parameters can also be set during operation without opening the unit. In the event of a power failure, all control parameter settings are retained.

The control parameters are assigned to 2 levels:

- “Service level”, and
- “Expert level” including communications, diagnostics and test

The “Service level” contains a small set of parameters to set up the thermostat for the HVAC system and to adjust the user interface. These parameters can be adjusted any time.

Change parameters at the “Expert level” carefully, as they impact the thermostat’s control performance and functionality.

### 3.12.1 Parameter setting via local HMI

**Enter only “Service” level**


1. Press buttons + and – simultaneously for 3 seconds. Release and press button + again for 3 seconds within 2 seconds. The display shows “P01”. Continue with step 2.

**Enter “Service” and “Expert” level.**

1. Press buttons + and – simultaneously for 3 seconds. Release and press button – again for 3 seconds within 2 seconds. The display shows “P01” and “service”.

**Adjust parameters**

2. Repeatedly press the + or – button to select the required parameter.



3. Press + and – simultaneously. The current value of the selected parameter begins to flash, allowing you to change the value by repeatedly pressing + or –.
4. The next parameter is displayed when you press + and – again simultaneously.
5. Repeat steps 2 to 4 to display and change additional parameters.
6. Press + or – until “End” is displayed, and then press + and – simultaneously to save the change and exit parameter entry mode.

**Reset parameters**

The factory setting for the control parameters can be reloaded via parameter P71, by changing the value to “ON”, and confirming by pressing buttons + and – simultaneously. The display shows “8888” during reload.

### 3.12.2 Parameter setting / download via tool

---

Control parameters can be adjusted via bus either by parameter download during commissioning or during normal operation with a tool like ACS700.

With the ACS700 tool, the parameters can be changed...

- during commissioning via parameter download (all parameters)
- during normal operation via Popcard (most of the parameters)



**ACS Service**



**ACS Operating**

**OZW772 Web server,  
RMZ792 bus operator  
unit**

Most parameters can be changed during normal operation using the OZW772 web server or the RMZ792 bus operator unit.



**ETS3 Professional**

Only the parameters for device address can be downloaded via ETS3 Professional. This is to simplify and avoid a conflict.

It allows you to further engineer communication objects of an RDU previously commissioned via local HMI or ACS (assigning communication objects to group addresses).

Notes:

- The basic application can only be changed via parameter download with ACS.
- The RDU KNX thermostats require version ETS3f or higher / ACS700 version 5.11 or higher.

**Connecting a KNX tool**

Connecting a KNX commissioning / operating tool to the RDU is described in section 4.2.

### 3.12.3 Parameters of the "Service level"

Parameter	Name	Factory setting	Range
	<b>Service level</b>		
P01	Control sequence	1 = Cooling only	0 = Heating only 1 = Cooling only 2 = H/C changeover manual 3 = H/C changeover auto
P02	Operation via room op selector	1	1 = Auto - Protection 2 = Auto - Comfort - Economy - Protection
P04	Unit	C (0)	C = ° Celsius F = ° Fahrenheit
P05	Measured value correction	0 K	-3 ... 3 K
P06	Standard display	0	0 = Room temperature 1 = Setpoint
P07	Additional display information	0	0 = --- (No display) 1 = °C and °F 2 = Outside temperature (via bus) 3 = Time of day (12h) (via bus) 4 = Time of day (24h) (via bus)
P08	Comfort basic setpoint	21 °C	5 ... 40 °C
P09	Comfort setpoint minimum	5 °C	5 ... 40 °C
P10	Comfort setpoint maximum	35 °C	5 ... 40 °C
P11	Economy heating setpoint	15 °C	OFF, 5 ... WCoolEco; WCoolEco = 40 °C max
P12	Economy cooling setpoint	30 °C	OFF, WHeatEco ... 40 °C; WHeatEco = 5C min
P14	Button lock	0	0 = Unlocked 1 = Auto lock 2 = Manual lock

Note: Parameter display depends on selected application and function.

### 3.12.4 Parameters of the "Expert level with diagnostics and test"

Parameter	Name	Factory setting	Range
	<b>Expert level</b>		
P30	Heat P-band Xp / switching diff	2 K	0.5 ... 6 K
P31	Cool P-band Xp / switching diff	1 K	0.5 ... 6 K
P33	Dead zone Comfort mode	2 K	0.5 ... 5 K
P35	Integral action time Tn	5 min	0...10 min
P36	H/C ch'over swi point cooling	16 °C	10...25 °C
P37	H/C ch'over swi point heating	28 °C	27...40 °C
P38	Input X1	3 = Op mode c/o	0 = --- (no function) 1 = Room temp ext. sensor / Return air temp (AI) 2 = H/C changeover (AI/DI) 3 = Operating mode contact (DI) 4 = Dew point sensor (DI) 5 = Enable electric heater (DI) 6 = Fault input (DI) 7 = Monitor input (Digital) 8 = Monitor input (Temp)
P39	Normal position input X1	0 (N.O.)	0 = Normally open / Open 1 = Normally closed / Close
P40	Input X2	1 = Ext. sensor	0 = --- (no function) 1 = Room temp ext. sensor / Return air temp (AI) 2 = H/C changeover (AI/DI) 3 = Operating mode contact (DI) 4 = Dew point sensor (DI) 5 = Enable electric heater (DI) 6 = Fault input (DI) 7 = Monitor input (Digital) 8 = Monitor input (Temp)
P41	Normal position input X2	0 (N.O.)	0 = Normally open / Open 1 = Normally closed / Close
P63	Supply air limit value min	0%	0...P64 (%)
P64	Supply air limit value max	100%	P63...100 (%)
P65	Protection heating setpoint	8 °C	OFF, 5...WCoolProt; WCoolProt = 40 °C max
P66	Protection cooling setpoint	OFF	OFF, WHeatProt... 40; WHeatProt = 5°C min
P68	Temporary Comfort mode	0 (= OFF)	0...360 min
P69	Temporary Comfort setpoint	OFF	OFF = Disabled ON = Enabled
P71	Restore factory setting	OFF	OFF = Disabled ON = Reload start "8888" is displayed for 3s during reload process

Parameter	Name	Factory setting	Range
	<b>Communications</b>		
P81	Device address 1)	255	1...255
P82	Geographical zone (apartment) 2)	---	---, 1...126
P83	Geographical zone (room) 2)	1	---, 1...63
P87	Air distribution zone	---	---, 1...31
P88	Transformation Precomfort	0	0 = Economy 1 = Comfort

- 1) Physical address = Area.Line.DeviceAddress. Factory setting for Area = 0, Line = 2.  
Can be changed by special management service e.g. from line coupler or via ACS commissioning tool.
- 2) Type = geographical zone A.R.S. In RDG RDU sub zone = fixed value 1


Parameter	Name	Range
	<b>Diagnostics &amp; test</b>	
d01	Application number	NONE = (No application) Sd = Single duct SdEL = Single duct with electric heater
d02	X1 state	0 = Not activated (for DI) 1 = Activated (DI) 0...49 °C = Current temp. value (for AI) 00 ☀ = H/C Input shorted 100 ⚡ = H/C Input open
d03	X2 state	0 = Not activated (for DI) 1 = Activated (DI) 0...49 °C = Current temp. value (for AI) 00 ☀ = H/C Input shorted 100 ⚡ = H/C Input open

- 3) This parameter can only be quit when the setting is back at “---”.  
Press buttons + and – simultaneously to escape.

## 4. Handling

### 4.1 Mounting and installation

Mount the room thermostat on a recessed rectangular conduit box with 60.3 mm fixing centers. Do not mount on a wall in niches or bookshelves, behind curtains, above or near heat sources, or exposed to direct solar radiation. Mount about 1.5 m above the floor.



#### Mounting



- Mount the room thermostat in a clean, dry indoor place without direct airflow from a heating / cooling device, and not exposed to dripping or splash water
- In case of limited space in the conduit box, use mounting bracket ARG70.3 to increase the headroom by 10 mm

#### Wiring



See Mounting Instructions M3172 [3] enclosed with the thermostat.

- Comply with local regulations to wire, fuse and earth the controller.
- The AC 230 V mains cable and the AC 24 V supply line must have an external fuse or circuit breaker with a rated current of no more than 10 A.
- Isolate the cables of SELV inputs X1-M/X2-M for 230 V if the conduit box carries AC 230 V mains voltage.
- Inputs X1-M or X2-M of different units (e.g. summer/winter switch) may be connected in parallel with an external switch. Consider overall maximum contact sensing current for switch rating.
- Isolate the cables of KNX communication input CE+ / CE- for 230 V if the conduit box carries AC 230 V mains voltage.
- No metal conduits.
- No cables provided with a metal sheath.
- Disconnect from supply before opening the cover.

### 4.2 Commissioning

#### Applications

The room thermostats are delivered with a fixed set of applications.

Select and activate the relevant application during commissioning using one of the following tools:

- Local DIP switch and HMI
- Synco ACS
- ETS3 Professional

*(Parameter and application download with ETS3 will be implemented later)*

## DIP switches

Set the DIP switches before snapping the front panel to the mounting plate, if you want to select an application via **DIP switches**.

All DIP switches need to be set to "OFF" (remote configuration), if you want to select an application via **commissioning tool**.


After power is applied, the thermostat resets and all LCD segments flash, indicating that the reset was correct. After the reset, which takes about 3 seconds, the thermostat is ready for commissioning by qualified HVAC staff.

If all DIP switches are OFF, the display reads "NONE" to indicate that application commissioning via a tool is required.

**Note:** Each time the application is changed, the thermostat reloads the factory setting for all control parameters, except for KNX device and zone addresses!

## Connect tool

Connect the Syncro ACS or ETS3 Professional tools to the KNX bus cable at any point for commissioning:



3172A04

ACS and ETS3 require an interface:

- RS232 KNX interface (e.g. Siemens N148 / UP146 / UP152)
- OCI700.1 USB-KNX interface

**Note:** An external KNX bus power supply is required if an RDU is connected directly to a tool (ACS700 or ETS3) via KNX interface.

## Control parameters

The thermostat's control parameters can be set to ensure optimum performance of the entire system.

The parameters can be adjusted using

- Local HMI
- Syncro ACS
- ETS3 Professional

Parameter and application *download* with ETS3 will be implemented later.

The control parameters of the thermostat can be set to ensure optimum performance of the entire system (see section 3.11, control parameters).

Control sequence	<ul style="list-style-type: none"> <li>The control sequence may need to be set via parameter P01 depending on the application. The factory setting is as follows:</li> </ul>						
	<table border="1"> <thead> <tr> <th>Application</th><th>Factory setting P01</th></tr> </thead> <tbody> <tr> <td>Single duct</td><td>1 = cooling only</td></tr> <tr> <td>Single duct with el. heater</td><td>Not adjustable</td></tr> </tbody> </table>	Application	Factory setting P01	Single duct	1 = cooling only	Single duct with el. heater	Not adjustable
Application	Factory setting P01						
Single duct	1 = cooling only						
Single duct with el. heater	Not adjustable						
Calibrate sensor	<ul style="list-style-type: none"> <li>Recalibrate the temperature sensor if the room temperature displayed on the thermostat does not match the room temperature measured (after min. 1 hour of operation). To do this, change parameter P05</li> </ul>						
Setpoint and range limitation	<ul style="list-style-type: none"> <li>We recommend to review the setpoints and setpoint ranges (parameters P08...P12) and change them as needed to achieve maximum comfort and save energy</li> </ul>						
<b>Programming mode</b>	<p>The programming mode helps identify the thermostat in the KNX network during commissioning.</p> <p>Press buttons "operating mode"  and "+" simultaneously for 6 sec to activate programming mode, which is indicated on the display with "PrO9". Programming mode remains active until thermostat identification is complete.</p>						
<b>Assign KNX group addresses</b>	Use ETS3 Professional to assign the KNX group addresses of the thermostat's communication objects.						
<b>KNX serial number</b>	Each device has a unique KNX serial number inside the front panel. An additional sticker with the same KNX serial number is enclosed in the packaging box. This sticker is intended for installers for documentation purposes.						

## 4.3 Operation

See also Operating Instructions B3172 [2] enclosed with the thermostat.


### Layout



- 1 Operating mode selector / Protection  
2 Adjust setpoint and control parameters

Button operation	User action	Effect, description
	Normal operation	Actual operating mode and state are indicated by symbols
	Press any button (thermostat in normal operation)	Backlit LCD turns on and... (see below for further action) After the last operation and a timeout of 20 seconds, the LCD backlight turns off
	Press left button	Change operating mode
	Press left button (P01 = 2)	Toggle between heating and cooling
	Press left button while "Operating mode" via bus is Economy	Activate "Extend Comfort mode" (for details, see page 16)
	Press left button >5 seconds	Activate / deactivate button lock
	Press + or -	Adjusts the Comfort room temperature setpoint . Thermostat changes to Comfort mode
	Press + and - >3 seconds, release, then press + again >3 seconds	Go to parameter setting mode "Service level"
	Press + and - >3 seconds, release, then press - again >3 seconds	Go to parameter setting mode "Expert level", diagnostics and test
	Press operating mode button and "+" simultaneously for 6 seconds	Enter (KNX) programming mode

## Display



- 3 Heating/cooling mode
- 6 Cooling
- 7 Heating,
- 8 Electrical heater active
- 4 Additional user information, like outdoor temperature or time of day from KNX bus
- 5 Indicates fault or reminder
- 6 Condensation in room (dewpoint sensor active)
- 7 Temporary comfort prolong active
- 8 Primary fan is active (only supported with Synco700 primary controller)
- 9 Button lock active
- 10 Weekday 1...7 from KNX bus (1 = Monday / 7 = Sunday)

1 Operating mode

Protection

Comfort

Economy

Auto Timer according to schedule  
Auto  
(via KNX)

2 Displays room temperature, setpoints and control parameters.

Symbol indicates the current room temperature

## 4.4 Remote operation

---

The RDG thermostats can be operated from a remote location using a OZW772 / OZW775 web server, a RMZ792 bus operating unit or the ACS Operating tool.

## 4.5 Disposal

---



The device is classified as waste electronic equipment in terms of the European Directive 2002/96/EC (WEEE) and should not be disposed of as unsorted municipal waste.

The relevant national legal rules must be adhered to.

Regarding disposal, use the systems setup for collecting electronic waste.

Observe all local and applicable laws.

## 5. Supported KNX tools

### 5.1 ETS3 Professional



ETS3 Professional

ETS3 Professional is an engineering tool. It is used to set up the communication of the RDU KNX thermostat and assigns the communication object to group addresses (S-mode).

Parameters are only used for choosing (making visible / hiding) the communication objects.

This Manual does not describe how to operate ETS3 Professional and commission a device. Refer to the KNX Manual for more details.




Note!

**Setting RDU KNX parameters is only supported by ETS3f or higher.**

#### 5.1.1 Parameter settings in ETS Professional

For setting the parameters, open the project and select a device.

To start the parameter settings, select **Edit**, then **Edit parameters**.



Notes:

- Parameters are only used to choose the communication objects
- The tool required is ETS3 Professional version 3f or higher!

### 5.2 ACS700 Service and Operating tool



ACS Service

ACS Operating

With the ACS700 tools, the RDU KNX thermostats can be commissioned (physical address, application, parameters). They can be operated or monitored via bus during normal operation.

This Manual does not describe how the physical address is defined. Also, it only gives a brief overview of the main functionality of ACS.

For more information, refer to the ACS online help.




Note!


**Setting RDU KNX parameters is only supported by ACS700 Version 5.11 or higher.**

## 5.2.1 Parameter settings in ACS

In the **ACS Service** program, select **Plant**, then **Open** to open the plant.  
To start the parameter settings, select **Applications**, then **Parameter settings...**:




The **application** and **control parameters** can be adjusted and downloaded.  
Column *Line no.* contains the parameter number as shown in the parameter table.  
Refer to section 3.11, control parameters.



## 5.2.2 Operation and monitoring with ACS

### ACS Operating


In the **ACS Operating** program, select **Plant**, then **Open** to open the plant.  
To start monitoring and operation, select **Applications**, then **Popcard**



Parameter settings in  
ACS Operating

ACS Operating supports parameter settings even during normal operation.  
To change a control parameter, select **Popcard**, then **Settings**.


- Notes:
- Make sure you have logged on with sufficient access right
  - Only control parameter can be changed, no application!



## Plant diagram in ACS Operating

ACS Operating offers plant diagrams for easy monitoring and operation of the thermostat.


To start this application, select **Applications**, then **Plant diagram**



ACS provides standard plant diagrams for RDU KNX thermostats, which depend on the configuration as follows:

Plant type	Application
Single duct	
Single duct with electric heater	

### 5.2.3 Operation and monitoring with OZW772



The OZW772 web server enables users to operate a Syncro HVAC system from a remote location – via PC or from a smart phone via the web. A start page shows the most important data points. A combination of menu / path navigation enables users to access all data points quickly and straightforwardly. The entire installation can be visualized in the form of plant diagrams. Alarm and state messages can be forwarded to different message receivers, such as e-mail, SMS, etc.

For details, see Commissioning Instructions CE1C5701.

### 5.2.4 Operation and monitoring with RMZ972



The RMZ972 is a communicating operator unit designed for operating Syncro™ 700 and RDU KNX devices in a KNX network.

The operator unit is suited both for fixed installation and mobile use (e.g. for use by the service engineer).

Third-party devices cannot be operated with it.


For details, see Basic Documentation CE1P3113.

Note: The application cannot be displayed in the form of text, instead a number is used:  
(Parameter **Plant type** on menu **Basic setting**):

- 0 = no application
- 1 = single duct
- 2 = single duct and electric heater


## 6. Connection

### 6.1 Connection terminals



G, G0	Operating voltage SELV AC 24 V
L	Supply for electrical heater AC 230 V
X10, G0	Output for damper, VAV compact controller
Y21	Output for electrical heater
X1, X2	Multifunctional input for temperature sensor (e.g. QAH11.1) or potential-free switch
CE+	Factory setting: – X1 = Operating mode switchover contact – X2 = External sensor
CE-	(function can be selected via parameter P38 / P40). Measuring neutral for sensor and switch
M	KNX data +
CE+	KNX data -

### 6.2 Connection diagrams



N1	Room thermostat RDU341
Y1	Damper actuator, VAV compact controller
E1	Electrical heater
F	External fuse
S1, S2	Switch (keycard, window contact, etc.)
B1, B2	Temperature sensor (return air temperature, external room temperature, changeover sensor, etc.)
CE+	KNX data +
CE-	KNX data -

## 7. Mechanical design

### 7.1 General

The thermostats consist of 2 parts:

- Front panel with electronics, operating elements and built-in room temperature sensor
- Mounting base with power electronics

The rear of the mounting base carries the screw terminals.

The base fits on a rectangular conduit box with 60.3 mm fixing centers.

Slide the front panel in the mounting base and snap on.




1 Operating mode selector / Protection

2 Adjust setpoint and control parameters

## 7.2 Dimensions

Dimensions in mm



## 8. Technical data

Outputs	Operating voltage	SELV AC 24 V +/-20 %
	Rated voltage	AC 24 V
	Frequency	50/60 Hz
	Power consumption	Max. 2.5 VA / 0.9 W
Inputs	Control output Y21-N (N.O.)	AC 230 V
	Rating	Max. 5(2) A
	Control output Y10-G0	SELV DC 0...10 V
	Resolution	39 mV
Inputs	Current	Max. ±1 mA
	Multifunctional input X1-M/X2-M	
	Temperature sensor input:	
	Type	QAH11.1 (NTC)
KNX bus	Digital input:	Selectable (N.O./N.C.)
	Operating action	SELV DC 0...5 V/max 5 mA
	Contact sensing	4 kV, reinforced insulation
	Insulation against mains voltage (SELV)	Selectable
Operational data	Function input:	X1: P38 X2: P40
	External temperature sensor, heating/cooling changeover sensor, operating mode switchover contact, dewpoint monitor contact, enable elec- trical heater contact, fault contact, monitor input	
	Interface type	KNX, TP1-64 (electrically isolated)
	Bus current	20 mA
Bus topology: See KNX manual (reference documentation, see below)		
Operational data	Switching differential, adjustable	
	Heating mode	(P30) 2 K (0.5...6K)
	Cooling mode	(P31) 1 K (0.5...6K)
	Setpoint setting and range	
	Comfort	(P08) 21°C (5...40 °C)
	Economy	(P11-P12) 15°C/30°C (OFF, 5...40 °C)
	Protection	(P65-P66) 8°C/OFF (OFF, 5...40 °C)
	Multifunctional input X1/X2	Selectable 0...8
	Input X1 default value	(P38) 3 (Operating mode switchover)
	Input X2 default value	(P40) 1 (External temperature sensor)
	Built-in room temperature sensor	
	Measuring range	0...49 °C
	Accuracy at 25 °C	< ± 0.5 K
	Temperature calibration range	± 3.0 K
	Settings and display resolution	
	Setpoints	0.5 °C
	Current temperature value displayed	0.5 °C

Environmental conditions	Operation	As per IEC 721-3-3
	Climatic conditions	Class 3K5
	Temperature	0...+50 °C
	Humidity	<95 % r.h.
	Transport	As per IEC 721-3-2
	Climatic conditions	Class 2K3
	Temperature	-25...+60 °C
	Humidity	<95 % r.h.
	Mechanical conditions	Class 2M2
	Storage	As per IEC 721-3-1
Standards and directives	C€ conformity	Class 1K3
	EMC directive	2004/108/EC
	Low-voltage directive	2006/95/EC
	 C-tick conformity to EMC emission standard	AS/NZS 61000.6.3: 2007
	 Reduction of hazardous substances	2002/95/EC
	Product standards	
	Automatic electrical controls for household and similar use	EN 60730-1
	Special requirements for temperature-dependent controls	EN 60730-2-9
	Electronic control type	2.B (micro-disconnection on operation)
	Home and Building Electronic Systems	EN 50090-2-2
General	Electromagnetic compatibility	
	Emissions (residential)	IEC/EN 61000-6-3
	Immunity (industrial and residential)	IEC/EN 61000-6-2
	Safety class	II as per EN 60730
	Pollution class	Normal
	Degree of protection of housing	IP 30 as per EN 60529
	Connection terminals	Solid wires or prepared stranded wires 1 x 0.4...2.5 mm <sup>2</sup> or 2 x 0.4...1.5 mm <sup>2</sup>
Housing front color		RAL 9003 white
Weight without / with packaging		0.163 kg / 0.233 kg

# Index

---

## A

Air demand .....	40
Air heating / cooling changeover .....	23
Applications overview .....	22
Auto Timer mode .....	15
Automatic heating / cooling changeover .....	23

## B

Button lock .....	24
-------------------	----

## C

Changeover switch .....	23
Control output VAV .....	40
Control outputs configuration.....	33
Control outputs overview .....	33
Control parameters .....	47
Control sequences.....	25
Cooling demand.....	40

## D

<b>DC 0..10 V control signal .....</b>	33
Dew point monitoring .....	24, 34
Disposal .....	56

## E

Effect of Protection via time schedule .....	15
Electric heater.....	30
Enable / disable electric heater .....	34
Enable/disable electrical heater.....	30
Expert level parameters.....	47
Extension of Comfort mode .....	16
External / return air temperature.....	34
External / return air temperature sensor.....	24

## F

Fault.....	35
Fault on KNX .....	42
Fault, handling .....	36

## H

Heating / cooling changeover .....	34
Heating demand .....	40

## I

Integral action time .....	12
----------------------------	----

## M

Mounting and installation.....	52
Multifunctional inputs .....	34

## O

ON/OFF control output signals.....	33
Operating mode	
Priority intervention .....	14
Operating mode button.....	15
Operating mode switchover .....	34

## P

Parameter setting .....	47
Precomfort.....	15
Proportional band .....	12
Protection mode / Standby .....	13

## R

Remote heating / cooling changeover.....	23
Reset parameters.....	47

## S

Sensor input .....	34
Setpoint Comfort mode .....	32
Setpoint Economy mode .....	32
Setpoint limitation .....	19
Setpoint Protection mode .....	32
Setpoints and sequences .....	32
Standby / Protection mode .....	13
Supply air temperature .....	23
Switching differential .....	12

## T

Temperature out of range .....	36
Temporary setpoint.....	19
Time schedule change mode .....	15

## V

VAV changeover .....	23
VAV changeover via bus .....	25

## W

Window contact .....	15
Window state .....	13, 14, 34

Siemens Switzerland Ltd  
Industry Sector  
Building Technologies Division  
International Headquarters  
Gubelstrasse 22  
CH-6301 Zug  
Tel. +41 41-724 24 24  
[www.buildingtechnologies.siemens.com](http://www.buildingtechnologies.siemens.com)

© 2010 Siemens Switzerland Ltd  
Subject to change