


de Montageanleitung	Wetterschutz für Dreh-/Linearantrieb GDB/GLB...E
en Mounting instructions	Weather shield for rotary-/linear-type actuator GDB/GLB...E
fr Instructions de montage	Protection pour servomoteur rot/linéaire GDB/GLB...E
sv Monteringsinstruktion	Kapsling för vridande/linjärt spjällställdon GDB/GLB...E
nl Montage-handleiding	Beschermkap voor roterende/lineaire aandrijvingen GDB/GLB...E
it Istruzioni di montaggio	Protezione per il servocomandi rotativi/lineare GDB/GLB...E
fi Asennusohje	Sääsuojus kääntöliikk./työntöllike toimimootorille GDB/GLB...E
es Instrucciones de montaje	Protección para montaje de actuador rotativo/lineal GDB/GLB...E
da Monteringsvejledning	Kapsling til motor for dreje-/lineær-bevægelse GDB/GLB...E

ASK75.5


de Lieferumfang	sv Leverans	fi Toimituslaajuus
en Supply	nl Leveringsomvang	es Contenido
fr Contenu	it Contenuto	da Leverancens omfang




Masse in mm
Dimensions in mm
Dimensions en mm
Mått i mm
Afmetingen in mm
Dimensioni in mm
Mitat mm
Dimensiones en mm
Mål i mm

de Vorbereitung	sv Förberedelse	fi Valmistelu
en Preparation	nl Voorbereiding	es Preparación
fr Préparation	it Preparazione	da Forberedelse


GDB/GLB...1



GDB/GLB...2



GDB/GLB...1



GDB/GLB...2

