


de Montageanleitung	Wetterschutz für Dreh-/Linearantrieb GMA/GEB...E
en Mounting instructions	Weather shield for rotary-/linear-type actuator GMA/GEB...E
fr Instructions de montage	Protection pour servomoteur rot/linéaire GMA/GEB...E
sv Monteringsinstruktion	Kapsling för vridande/linjärt spjällställdon GMA/GEB...E
nl Montage-handleiding	Beschermkap voor roterende/lineaire aandrijvingen GMA/GEB...E
it Istruzioni di montaggio	Protezione per il servocomandi rotativi/lineare GMA/GEB...E
fi Asennusohje	Sääsuojus kääntöliikk./työntölliike toimimootorille GMA/GEB...E
es Instrucciones de montaje	Protección para montaje de actuador rotativo/lineal GMA/GEB...E
da Monteringsvejledning	Kapsling til motor for dreje-/lineær-bevægelse GMA/GEB...E


ASK75.6

de Lieferumfang	sv Leverans	fi Toimituslaajuus
en Supply	nl Leveringsomvang	es Contenido
fr Contenu	it Contenuto	da Leverancens omfang




de Vorbereitung	sv Förberedelse	fi Valmistelu
en Preparation	nl Voorbereiding	es Preparación
fr Préparation	it Preparazione	da Forberedelse

GMA/GEB...1



GEB...2




de Montage
en Mounting
fr Montage

sv Montering
nl Montage
it Montaggio

fi Asennus
es Montaje
da Montering

GMA/GEB...1



GEB...2

